How to connect serial console to Origin 350?

Published 03/24/2008

Symptom(s):

How to connect serial console to Origin 350?

Fact(s):

Origin 350
IRIX Operating System

SGI Solution:

"cu -l ttyd2" for Irix
"cu -l ttys0 -S38400" for Linux

Baud 38400
No Parity
8 Data Bits
1 Stop Bit
Hardware Flow Control on (RTS/CTS)

Answers others found helpful

- Origin Boot Fails due to BSN mismatch
- How to reset root password on Irix
- How to flash L1 firmware from IRIX
- How to flash an L1 and L2 controller from IRIX
- SGI® Man Page Library

Additional Details

Creation Date	03/24/2008 10:47 AM
Last modification	10/01/2015 02:21 AM
Published Date	03/24/2008
Products	• Servers and Clusters • SGI Origin/Onyx • Origin/Onyx Server • Software • Legacy Software • Operating Systems • IRIX • Workstations • SGI Tezro • O2 • Octane
Categories	• Knowledgebase • Technical Solution